NATIONAL RESEARCH UNIVERSITY HIGHER SCHOOL OF ECONOMICS

Faculty of Physics

Report

«Diffraction»

M. I. Blumenau



 $\begin{array}{c} {\rm Moscow} \\ 2021 \end{array}$

Contents

Introduction	2
Theoretical information	2
Single-slit diffraction	2
Diffraction on a lattice with N slits	3
Diffraction on a concentrating reflecting array	3
Equipment and methods	4
Experimental results	4
The first diffraction grating	5
The second diffraction grating	
The third diffraction grating	
The second experiment	7
Conclusion	8
References	8

Introduction

This report represents an assembly of an installation for observing diffraction on a reflecting diffraction grating. We studied the diffraction pattern for different gratings at different angles of incidence of light, determined the positions of the maxima. For each grid, we determined the number of strokes per unit length. Using a photodiode power meter, we measured the light intensity in maxima for the grating with which the greatest number of maxima was observed. After processing the obtained dependence, we determined the angle of the lattice bevel γ .

Theoretical information

Single-slit diffraction

Let the edges of the gap be located at $x = \pm b/2$, where b is the width of the gap. A plane monochromatic wave with a wave vector k at an angle θ_i to the normal vector to the lattice falls on the slit.




Figure 1. Fraunhofer diffraction on the slit.

The phase difference between the waves emitted from the coordinate x = 0 and x is equal to $\delta_1 = -kx(\sin\theta + \sin\theta_i)$. We obtain:

$$E(\theta) \propto \int_{b/2}^{b/2} \exp(-i\delta_1(x)) dx \propto \int_{b/2}^{b/2} \exp(-ikx(\sin\theta + \sin\theta_i)) dx \tag{1}$$

$$E(\theta) \propto \frac{\sin(kb/2(\sin\theta + \sin\theta_i))}{kb/2(\sin\theta + \sin\theta_i)}$$
 (2)

Diffraction on a lattice with N slits

The path difference between the secondary waves formed by adjacent slits is $delta = dk(\sin \theta + sin\theta_i)$, in addition, the field emitted by the slot with the number n is $E_n = E_1 \exp(-i\delta n)$. Hence the resulting field:

$$E = E_1 * \sum_{0}^{N-1} \exp(-i\delta n) = E_1 \exp(i\delta(N/2 - 1)) \frac{\sin(N\delta/2)}{\sin(\delta/2)}$$
 (3)

From here we can obtain the intensity:

$$I \propto E^2 \propto \left(\frac{\sin(kb/2(\sin\theta + \sin\theta_i))}{kb/2(\sin\theta + \sin\theta_i)}\right)^2 \cdot \left(\frac{\sin(Nkd/2(\sin\theta + \sin\theta_i))}{\sin(kd/2(\sin\theta + \sin\theta_i))}\right)^2$$
(4)

The right multiplier is responsible for the position of the observed maxima, it also gives us the following condition:

$$d(\sin\theta + \sin\theta_i) = m\lambda,\tag{5}$$

where m is an integer called the order of the maximum.

Diffraction on a concentrating reflecting array

Because of the geometry of the concentrating reflecting grid, the multiplier $E_1(\theta)$ will change, while the second multiplier will remain the same.

$$I \propto E^2 \propto \left(\frac{\sin(kb/2(\sin(\theta - \gamma) + \sin(\theta_i - \gamma)))}{kb/2(\sin(\theta - \gamma) + \sin(\theta_i - \gamma))}\right)^2 \cdot \left(\frac{\sin(Nkd/2(\sin\theta + \sin\theta_i))}{\sin(kd/2(\sin\theta + \sin\theta_i))}\right)^2$$
(6)




Figure 2. Diffraction on a concentrating reflecting array.

Here we will be interested in the first, changed multiplier, which is the curve that envelopes the intensity.

The angle at which the maximum intensity is observed corresponds to the mirror reflection of the incident light, is called the angle of brightness, and is defined by the following expression:

$$\varphi_B = 2\gamma - \theta_i \tag{7}$$

We can also calculate the amount of slits per unit length using

$$N_{slit} = \alpha/(\lambda \cdot 10^{-6}) \tag{8}$$

Equipment and methods

We used a laser with a wavelength of 520 nm, reflecting diffraction gratings with different lattice constants, a tape measure fixed on the wall, a ruler, and a light intensity analyzer.

The results were collected by hand and later processed with Python. Schematic diagram of the installation attached below:




Figure 3. Installation diagram.

Source code link:

https://github.com/burunduk387/HSE-FF/tree/main/LabOptics/Diffraction

Experimental results

We fixed each diffraction grating in front of the screen, which was a wall with a fixed tape measure for measuring the coordinates of the beams on the screen. We moved the laser to change the angles of incidence of the beam on the grid and recorded the results. We repeated this experiment for all three gratings. Distance between the wall and the diffraction gratings remained the same throughout all experiments and was L=130 cm. Y-coordinate distance between the diffraction grating and the laser also remained the same and was a=51.5 cm. Different angles were achived by moving the laser X-wise. Raw data for angles different from $\theta_i=0$ are available in the GitHub repository in order not to overload this report with information.

The first diffraction grating

The results are represented in a table below.

Table 1. Table with raw data for $\theta_i = 0$.

Order of the maximum	Coordinate of the maximum, cm
-1	77
0	173.5
1	282.5




Figure 4.

Unfortunately, our measuring tape was not long enough, so we were able to make only one measurement. After fitting a line, we get its coeffitiets. We obtain $N_{slit} = 1190 \pm 7mm^{-1}$.

The second diffraction grating

The results are represented in a table below.

Table 2. Table with raw data for $\theta_i = 0$.

Order of the maximum	Coordinate of the maximum, cm
-2	55
-1	124
0	166
1	207
2	266




Figure 5.

After fitting lines, we get their coeffitiets. We obtain $N_{slit} = 597 \pm 8 mm^{-1}$.

The third diffraction grating

The results are represented in a table below.

Table 3. Table with raw data for $\theta_i = 0$.

Order of the maximum	Coordinate of the maximum, cm
-2	118
-1	141
0	161
1	181
2	202




Figure 6.

After fitting lines, we get their coeffitiets. We obtain $N_{slit}=316\pm3mm^{-1}$.

The second experiment

For the third grating, we attempted to find γ using a light intensity analyzer. The results we got and the theoretical curve that was fitted are shown below.




Figure 7.

We got $\gamma = 0.012 \pm 0.005$ rad.

Conclusion

We attempted to calculate the amount of splits per unit length for three diffraction graters. For the third one we also tried to find its bevel angle. The results are:

- $\bullet \ N_{slit1} = 1190 \pm 7 mm^{-1}$
- $\bullet~N_{slit2}=597\pm8mm^{-1}$
- $N_{slit3} = 316 \pm 3mm^{-1}$.
- $\gamma = 0.012 \pm 0.005 \text{ rad}$

References

[1] Diffraction. Guidelines for the Optics Workshop, 2021.